



Undercover Tents, LLC

Operating Instructions

Convection Oven

This unit has already been checked by Undercover Tents to ensure it is functioning properly.

1. Ensure unit is plugged into proper outlet
2. Make sure propane is connected and turned on
 - a. If it's turned off, slowly open the valve on the tank
3. To begin using the oven, turn the top knob *right* [clockwise] to "cook" position
 - a. The oven will automatically come on and ignite
 - i. An orange light will light up to indicate burner ignition
4. Set temperature to desired cooking temperature
 - a. Orange light will turn *off* when oven is up to temperature
5. You're ready to cook - oven light may come back on a few times during cooking as the door opens and closes, losing heat
6. When cooking is complete, turn top knob all the way to the left [counter-clockwise] to "cool down" position
7. Please allow oven to cool for a minimum of 10 minutes

If at any time you smell propane or an odor, discontinue use and turn the tank off

If this is an emergency situation, call 911